

POTENZA REMOTE

**DEVICE SELECTION**  
Use one remote to control multiple devices.

**POWER**

**LIVE**  
Return to watching live TV.

**SKIP AHEAD 30 SECONDS**

**CONTROLS**  
In STB mode, these control the DVR functions. In other modes, these can control other input devices.

**INFORMATION NAVIGATION ARROWS**

**EXIT**

**PAGE +/-**  
Page up or down in lists and Interactive Program Guide.

**CHANNEL NAVIGATION**

**ON DEMAND**  
Access video on demand.

**LAST**

**FAVORITE**  
View your favorite channels.

**NUMBER PAD**  
Enter channel or PIN.

**CLOSED CAPTION**  
Turn closed caption on/off.

**SETUP**  
Use for programming sequences of devices controlled by the remote.

**MENU**

**OK**  
Choose the highlighted option.

**GUIDE**

**DAY**  
Jumps forward or backward one day of program listings.

**RESTART TV**

**VOLUME CONTROL**

**MUTE**

**ASPECT RATIO**  
Temporarily change the conversion mode from Original Size of Fit to Screen.

**INPUT**  
In TV control mode, will change the input of the device you are controlling.